

Таблица ВАО 2

Тип	Габаритные, установочные и присоединительные размеры									
	l31	d1	d10	l1	l10	l30	h	h5		
BAO2-450S2	315	70		140	560	1360	450			
BAO2-450M2						1410				
BAO2-450LA2					710	1490				
BAO2-450LB2						1620				
BAO2-450S4		100	35	210	630	1525				
BAO2-450M4					710	1585				
BAO2-450LA4		100	35	210	800	1780				
BAO2-450LB4					800	1835				
BAO2-450M6		100	35	210	710	1605				
BAO2-450LA6					710	1725				
BAO2-450LB6		100	35	210	800	1855				
BAO2-450LA8					710	1705				
BAO2-450LB8		100	35	210	800	1835				
BAO2-560S4					355	110			42	210
BAO2-560M4	710	1745								
BAO2-560LA4	800	1865								
BAO2-560LB4	900	2045								
BAO2-560S6	110	42	210	630			1675			
BAO2-560M6				710			1745			
BAO2-560LA6	110	42	210	800			1865			
BAO2-560LB6				900			2045			
BAO2-560S8	110	42	210	630			1605			
BAO2-560M8				710			1745			
BAO2-560LA8	110	42	210	800			1865			
BAO2-560LB8				900			2045			
BAOY-630S4	375	140	42	250			1000	2245		
BAO2-630S4							1120	2375		
BAOY-630M4					1250	2585				
BAO2-630M4							1120	2263		
BAOY-630L4					1250	2483				
BAO2-630L4							1120	2253		
BAO2-630S6					1250	2473				
BAO2-630M6							1120	2253		
BAO2-630S8					1250	2473				
BAO2-630M8							1120	2253		